

**NEUTRIK**



## BTXX

Speed boot assembly tool to press the XX boot onto shell.

### BTXX 2nd view



**Technical Information**

| Product |      |
|---------|------|
| Title   | BTXX |

| Mechanical |  |
|------------|--|
| Wiresize   |  |