NX Units to meet every temperature control need

- Temperature Input Unit (NX-TS)
  Standard and high-speed, high-precision
  temperature measurement and control
- Heater Burnout Detection Unit (NX-HB)
  Temperature control with heater burnout detection
  in conjunction with a temperature input unit and PID
  instructions

NX-TS2101   NX-TS3101   NX-TS2201   NX-TS3201

NX-HB3101

General Specifications

| Item		Specification
Enclosure		Mounted in a panel
Grounding method		Ground to 100 Ω or less
Operating environment	Ambient operating temperature	0 to 55°C
	Ambient operating humidity	10% to 95% (with no condensation or icing)
	Atmosphere	Must be free from corrosive gases.
	Ambient storage temperature	−25 to 70°C (with no condensation or icing)
	Altitude	2,000 m max.
	Pollution degree	2 or less: Conforms to JIS B3502 and IEC 61131-2.
	Noise immunity	2 kV on power supply line (Conforms to IEC61000-4-4.)
	Overvoltage category	Category II: Conforms to JIS B3502 and IEC 61131-2.
	EMC immunity level	Zone B
	Vibration resistance	Conforms to IEC 60068-2-6. 5 to 8.4 Hz with 3.5-mm amplitude, 8.4 to 150 Hz, acceleration of 9.8 m/s^2, 100 min each in X, Y, and Z directions (10 sweeps of 10 min each = 100 min total)
	Shock resistance	Conforms to IEC 60068-2-27. 147 m/s^2, 3 times each in X, Y, and Z directions
Applicable standards *		cULus: Listed (UL508), ANSI/ISA 12.12.01, EU: EN 61131-2, C-Tick or RCM, KC Registration, NK, LR

* Refer to the OMRON website (www.ia.omron.com) or ask your OMRON representative for the most recent applicable standards for each model.

System Configurations

Connected to a CPU Unit

The following figure shows a system configuration when NX Units are connected to an NX-series CPU Unit.

Support software
(Sysmac Studio)

● CPU Rack

NX-series CPU Unit
NX1P2-□□□□□□□

Connection to built-in
EtherNet/IP™ port

Built-in EtherCAT® port

NX Units

End Cover

EtherCAT

EtherCAT Slave Terminal

NX Units

EtherCAT Coupler Unit

Connected to an EtherCAT Coupler Unit

The following figure shows an example of the system configuration when an EtherCAT Coupler Unit is used as a Communications Coupler Unit.

Support software
(Sysmac Studio)

Connection to peripheral USB port
or built-in EtherNet/IP™ port on
CPU Unit or Industrial PC *1

ESI files

EtherCAT master *2
NJ/NX-series CPU Unit, NY-series Industrial PC, or
master from another manufacturer

Built-in EtherCAT® port

●EtherCAT Slave Terminal

Support software
(Sysmac Studio)

Communications cable
Ethernet cables

Peripheral USB port.

NX Series
EtherCAT Coupler Unit
NX-ECC20□

Connection to peripheral USB
port on EtherCAT Coupler Unit

ESI files

NX Units

End Cover

*1. The connection method for the Sysmac Studio depends on the model of the CPU Unit or Industrial PC.
*2. An EtherCAT Slave Terminal cannot be connected to any of the OMRON CJ1W-NC□81/□82 Position Control Units even though they can operate as EtherCAT masters.

Note: To check whether NX Units can be connected to your CPU Unit or Communications Coupler Unit, refer to the user's manual for the CPU Unit or Communications Coupler Unit.

Model Number Structure

$$NX-\square\square\square\square\square\square$$
(1)   (2) (3)   (4)

(1) Unit type

No.	Specification
TS	Temperature input
HB	Heater burnout detection

(2) Number of points

No.	Specification
2	2 points
3	4 points
4	8 points

(3) I/O type

• Temperature Input Units

No.	Sensor type
1	Thermocouple
2	Resistance thermometer

• Heater Burnout Detection Units

No.	Internal I/O common processing of control outputs
1	NPN
2	PNP

(4) Other specifications

• Temperature Input Units

No.	Conversion time	Resolution	I/O refreshing method	
			Free-Run refreshing only *1	Switching Synchronous I/O refreshing *2 and Free-Run refreshing
01	250 ms/Unit	0.1°C max. *3	Yes	---
02	10 ms/Unit	0.01°C max.	Yes	---
04	60 ms/Unit	0.001°C max.	Yes	---

*1. Free-Run refreshing
*2. Synchronous I/O refreshing
*3. The resolution is 0.2°C max. when the input type is R, S, or W.

• Heater Burnout Detection Units

No.
01

Ordering Information

International Standards

- The standards are abbreviated as follows: U: UL, U1: UL (Class I Division 2 Products for Hazardous Locations), C: CSA, UC: cULus, UC1: cULus (Class I Division 2 Products for Hazardous Locations), CU: cUL, N: NK, L: Lloyd, CE: EU Directives, RCM: Regulatory Compliance Mark, and KC: KC Registration.
- Contact your OMRON representative for further details and applicable conditions for these standards.

Temperature Input Units

Unit type	Product name	Specification							Model	Standards
		Number of points	Input type	Resolution (25°C)	Over all accuracy (25°C)	Conversion time	I/O refreshing method	Terminals		
NX-series Temperature Input Unit	Thermocouple Input type	2 points	Thermocouple	0.1°C max. *1	Refer to the *Reference accuracy and temperature coefficient according to the input type and measurement temperature of NX-series Temperature Input Unit in the Sysmac Integrated Catalog* (Cat. No. P072).	250 ms/ Unit	Free-Run refreshing	16 Terminals	NX-TS2101	UC1, N, L, CE, RCM, KC
		4 points						16 Terminals x 2	NX-TS3101	
		2 points		0.01°C max.		10 ms/Unit		16 Terminals	NX-TS2102	
		4 points						16 Terminals x 2	NX-TS3102	
		2 points		0.001°C max.		60 ms/Unit		16 Terminals	NX-TS2104	
		4 points						16 Terminals x 2	NX-TS3104	
	Resistance Thermometer Input type	2 points	Resistance Thermometer (Pt100/Pt1000, three-wire) *2	0.1°C max.		250 ms/ Unit		16 Terminals	NX-TS2201	
		4 points						16 Terminals x 2	NX-TS3201	
		2 points		0.01°C max.		10 ms/Unit		16 Terminals	NX-TS2202	
		4 points						16 Terminals x 2	NX-TS3202	
		2 points		0.001°C max.		60 ms/Unit		16 Terminals	NX-TS2204	
		4 points						16 Terminals x 2	NX-TS3204	

*1. The resolution is 0.2°C max. when the input type is R, S, or W.
*2. The NX-TS2202 and NX-TS3202 only support Pt100 three-wire sensor.

Heater Burnout Detection Units

Unit type	Product name	Specification							Model	Standards
		CT input section		Control output section						
		Number of inputs	Maximum heater current	Number of outputs	Internal I/O common	Maximum load current	Rated voltage	I/O refreshing method		
NX-Series Heater Burnout Detection Unit	Heater Burnout Detection Unit	4	50 A AC	4	NPN	0.1 A/point, 0.4 A/Unit	12 to 24 VDC	Free-Run refreshing	NX-HB3101	UC1, CE, N, RCM, KC
					PNP		24 VDC		NX-HB3201	

Optional Products

Product name	Specification	Model	Standards
Unit/Terminal Block Coding Pins	Pins for 10 Units (30 terminal block pins and 30 Unit pins)	**NX-AUX02**	---

Product name	Specification				Model	Standards
	No. of terminals	**Terminal number indications**	**Ground terminal mark**	**Terminal current capacity**		
Terminal Block	16	A/B	Not provided	10 A	**NX-TBA162**	---

Product name	Specification	Model	Standards
Current Transformer (CT)*	Hole diameter: 5.8 mm	**E54-CT1**	---
	Hole diameter: 12.0 mm	**E54-CT3**	---

* Can be connected to the NX-HB Heater Burnout Detection Unit.

Accessories

Not included.

External Interface

Screwless Clamping Terminal Block Type

**Temperature Input Unit (Resistance Thermometer Input type)/Heater Burnout Detection Unit**

12mm Width

24mm Width

Letter	Item	Specification
(A)	NX bus connector	This connector is used to connect to another Unit.
(B)	Indicators	The indicators show the current operating status of the Unit.
(C)	Terminal block	The terminal block is used to connect to external devices. The number of terminals depends on the Unit.

# Temperature Input Unit (Thermocouple Input type)

12mm Width

24mm Width

Letter	Item	Specification
(A)	NX bus connector	This connector is used to connect to another Unit.
(B)	Indicators	The indicators show the current operating status of the Unit.
(C)	Terminal block	The terminal block is used to connect to external devices. The number of terminals depends on the Unit.
(D)	Cold junction sensor	This sensor is used to compensate the cold junction. The sensors are mounted on both left and right terminal blocks for models with 24 mm width.

Terminal Blocks

12 mm width
16 terminals

12 mm width
16 terminals x 2

Letter	Item	Specification
(A)	Terminal number indications	The terminal number is identified by a column (A through D) and a row (1 through 8). Therefore, terminal numbers are written as a combination of columns and rows, A1 through A8 and B1 through B8. For a 24-mm-wide terminal block (16 terminals x 2), the left side contains terminals A1 through A8 and B1 through B8. The right side contains terminals C1 through C8 and D1 through D8. The terminal number indication is the same regardless of the number of terminals on the terminal block.
(B)	Release holes	A flat-blade screwdriver is inserted here to attach and remove the wiring.
(C)	Terminal holes	The wires are inserted into these holes.

Applicable Terminal Blocks for Each Unit Model

Unit model	Terminal Blocks				
	Model	No. of terminals	Terminal number indications	Ground terminal mark	Terminal current capacity
NX-TS2□□□	NX-TBA162	16	A/B	None	10 A
NX-TS3□□□	NX-TBA162	16	A/B	None	10 A
	NX-TBB162		C/D		
NX-HB3□01	NX-TBA162	16	A/B	Not provided	10A

Applicable Wires

Using Ferrules

If you use ferrules, attach the twisted wires to them.

Observe the application instructions for your ferrules for the wire stripping length when attaching ferrules.

Always use plated one-pin ferrules. Do not use unplated ferrules or two-pin ferrules.

The applicable ferrules, wires, and crimping tool are given in the following table.

Terminal type	Manufacturer	Ferrule model	Applicable wire (mm² (AWG))	Crimping tool
Terminals other than ground terminals	Phoenix Contact	AI0,34-8	0.34 (#22)	Phoenix Contact (The figure in parentheses is the applicable wire size.) CRIMPFOX 6 (0.25 to 6 mm², AWG24 to 10)
		AI0,5-8	0.5 (#20)	
		AI0,5-10		
		AI0,75-8	0.75 (#18)	
		AI0,75-10		
		AI1,0-8	1.0 (#18)	
		AI1,0-10		
		AI1,5-8	1.5 (#16)	
		AI1,5-10		
Ground terminals		AI2,5-10	2.0 *	
Terminals other than ground terminals	Weidmuller	H0.14/12	0.14 (#26)	Weidmuller (The figure in parentheses is the applicable wire size.) PZ6 Roto (0.14 to 6 mm², AWG 26 to 10)
		H0.25/12	0.25 (#24)	
		H0.34/12	0.34 (#22)	
		H0.5/14	0.5 (#20)	
		H0.5/16		
		H0.75/14	0.75 (#18)	
		H0.75/16		
		H1.0/14	1.0 (#18)	
		H1.0/16		
		H1.5/14	1.5 (#16)	
		H1.5/16		

* Some AWG 14 wires exceed 2.0 mm² and cannot be used in the screwless clamping terminal block.

When you use any ferrules other than those in the above table, crimp them to the twisted wires so that the following processed dimensions are achieved.

Finished Dimensions of Ferrules

8 to 10 mm

1.6 mm max. (except ground terminals)
2.0 mm max. (ground terminals)

2.4 mm max. (except ground terminals)
2.7 mm max. (ground terminals)

Using Twisted Wires/Solid Wires

If you use the twisted wires or the solid wires, use the following table to determine the correct wire specifications.

Terminals		Wire type				Wire size	Conductor length (stripping length)
		Twisted wires		Solid wire			
Classification	Current capacity	Plated	Unplated	Plated	Unplated		
All terminals except ground terminals	2 A or less	Possible	Possible	Possible	Possible	0.08 to 1.5 mm² AWG28 to 16	8 to 10 mm
	Greater than 2 A and 4 A or less		Not Possible	Possible *1	Not Possible		
	Greater than 4 A	Possible *1		Not Possible			
Ground terminals	---	Possible	Possible	Possible *2	Possible *2	2.0 mm²	9 to 10 mm

*1. Secure wires to the screwless clamping terminal block. Refer to the Securing Wires in the USER'S MANUAL for how to secure wires.
*2. With the NX-TB☐☐☐1 Terminal Block, use twisted wires to connect the ground terminal. Do not use a solid wire.


Conductor length (stripping length)

<Additional Information> If more than 2 A will flow on the wires, use plated wires or use ferrules.

Dimensions (Unit/mm)

Screwless Clamping Terminal Block Type
12 mm Width

24 mm Width

* The dimension is 1.35 mm for Units with lot numbers through December 2014.

Related Manual

Cat. No.	Model number	Manual name	Application	Description
W566	NX-TS☐☐☐☐ NX-HB☐☐☐☐	NX-series Analog I/O Units User's Manual for Temperature Input Units and Heater Burnout Detection Units	Learning how to use NX-series Temperature Input Units and Heater Burnout Detection Units	The hardware, setup methods, and functions of the NX-series Temperature Input Units and Heater Burnout Detection Units are described.

NX-TS

Standard and high-speed, high-precision temperature measurement and control

- Temperature Input Units for the NX-series modular I/O system
- Connect to other NX I/O Units and EtherCAT Coupler Units using the high-speed NX-bus
- Thermocouple and platinum resistance thermometer input models are available

Features

- Up to four temperature sensor inputs per unit
- Three sampling speeds, 250 ms, 60 ms, and 10 ms, are available to cover a wide range from general-purpose application to high-speed, high-precision control
- Moving average, input sensor disconnection detection, cold junction compensation enable/disable setting, and input correction
- Detachable front connector with screwless Push-In Plus terminals for easy installation and maintenance
- Connect to the CJ PLC using the EtherNet/IP™ bus coupler

Temperature Input Unit Specifications

Temperature Input Unit (Thermocouple Input type) 2 points NX-TS2101

| Unit name	Temperature Input Unit (thermocouple input type)	Model	NX-TS2101
Number of points	2 points	External connection terminals	Screwless clamping terminal block (16 terminals)
I/O refreshing method	Free-Run refreshing		
Indicators	TS indicator **TS2101** ■TS	Temperature sensor	K, J, T, E, L, U, N, R, S, B, WRe5-26, PLII
		Input conversion range	±20°C of the input range
		Absolute maximum rating	±130 mV
		Input impedance	20 kΩ min.
		Resolution	0.1°C max. *1
		Reference accuracy	*2
		Temperature coefficient	*2
		Cold junction compensation error	±1.2°C *3 *4
		Input disconnection detection current	Approx. 0.1 μA
Warm-up period	30 minutes	Conversion time	250 ms/Unit
Dimensions	12 (W) x 100 (H) x 71 (D)	Isolation method	Between the input and the NX bus: Power = Transformer, Signal = Photocoupler Between inputs: Power = Transformer, Signal = Photocoupler
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)	Dielectric strength	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
I/O power supply method	No supply	Current capacity of I/O power supply terminal	Without I/O power supply terminals
NX Unit power consumption	• Connected to a CPU Unit 1.25 W max. • Connected to a Communications Coupler Unit 0.90 W max.	Current consumption from I/O power supply	No consumption
Weight	70 g max.		
Installation orientation and restrictions	Installation orientation: • Connected to a CPU Unit: Possible in upright installation. • Connected to a Communications Coupler Unit: Possible in 6 orientations. Restrictions: The cold junction compensation error is restricted according to the installation orientation and the power consumption of adjacent Units. Refer to *Cold Junction Compensation Error Specifications for Units That Take a Thermocouple Input Type*.		
Terminal connection diagram	Temperature Input Unit NX-TS2101 A1 ─── B1 NC | NC NC | NC NC | NC NC | NC TC2+ | TC2− CJ1+ | CJ1− TC1+ | TC1− NC | NC A8 ─── B8 Cold junction sensor * Do not touch or remove. Thermocouple input		

*1. The resolution is 0.2°C max. when the input type is R, S, or W.
*2. Refer to *Reference Accuracy and Temperature Coefficient According to the Input Type and Measurement Temperature*.
*3. The overall accuracy is guaranteed for a set consisting of a cold junction sensor that is mounted on the terminal block and a Temperature Input Unit. Be sure to use the terminal block and the Temperature Input Unit together. A calibration control number is both displayed on the terminal block and the Unit. Make sure to return the terminal block (including a cold junction sensor mounted) and the Unit together for repair.
*4. Refer to *Cold Junction Compensation Error Specifications for Units That Take a Thermocouple Input Type* for the specifications for each set of operating conditions.

Temperature Input Unit (Thermocouple Input type) 2 points NX-TS2102

Unit name	Temperature Input Unit (thermocouple input type)	Model	NX-TS2102
Number of points	2 points	External connection terminals	Screwless clamping terminal block (16 terminals)
I/O refreshing method	Free-Run refreshing		
Indicators	TS indicator **TS2102** ■TS	Temperature sensor	K, J, T, E, L, U, N, R, S, WRe5-26, PLII
		Input conversion range	±20°C of the input range
		Absolute maximum rating	±130 mV
		Input impedance	20 kΩ min.
		Resolution	0.01°C max.
		Reference accuracy	*1
		Temperature coefficient	*1
		Cold junction compensation error	±1.2°C *2 *3
		Input disconnection detection current	Approx. 0.1 μA
Warm-up period	45 minutes	Conversion time	10 ms/Unit
Dimensions	12 (W) x 100 (H) x 71 (D)	Isolation method	Between the input and the NX bus: Power = Transformer, Signal = Digital isolator. Between inputs: Power = Transformer, Signal = Digital isolator
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)	Dielectric strength	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
I/O power supply method	No supply	Current capacity of I/O power supply terminal	Without I/O power supply terminals
NX Unit power consumption	• Connected to a CPU Unit 1.15 W max. • Connected to a Communications Coupler Unit 0.80 W max.	Current consumption from I/O power supply	No consumption
Weight	70 g max.		
Installation orientation and restrictions	Installation orientation: • Connected to a CPU Unit: Possible in upright installation. • Connected to a Communications Coupler Unit: Possible in 6 orientations. Restrictions: The cold junction compensation error is restricted according to the installation orientation and the power consumption of adjacent Units. Refer to *Cold Junction Compensation Error Specifications for Units That Take a Thermocouple Input Type*.		
Terminal connection diagram	Temperature Input Unit NX-TS2102 A1 — B1 NC / NC NC / NC NC / NC NC / NC TC2+ / TC2− CJ1+ / CJ1− TC1+ / TC1− NC / NC A8 — B8 Cold junction sensor * Do not touch or remove. Thermocouple input		

*1. Refer to *Reference Accuracy and Temperature Coefficient According to the Input Type and Measurement Temperature*.
*2. The overall accuracy is guaranteed for a set consisting of a cold junction sensor that is mounted on the terminal block and a Temperature Input Unit. Be sure to use the terminal block and the Temperature Input Unit together. A calibration control number is both displayed on the terminal block and the Unit. Make sure to return the terminal block (including a cold junction sensor mounted) and the Unit together for repair.
*3. Refer to *Cold Junction Compensation Error Specifications for Units That Take a Thermocouple Input Type* for the specifications for each set of operating conditions.

## Temperature Input Unit (Thermocouple Input type) 2 points NX-TS2104

Unit name	Temperature Input Unit (thermocouple input type)	**Model**	NX-TS2104
Number of points	2 points	**External connection terminals**	Screwless clamping terminal block (16 terminals)
I/O refreshing method	Free-Run refreshing		
Indicators	TS indicator **TS2104** ■TS	**Temperature sensor**	K, J, T, E, L, U, N, R, S, WRe5-26, PLII
		Input conversion range	±20°C of the input range
		Absolute maximum rating	±130 mV
		Input impedance	20 kΩ min.
		Resolution	0.001°C max.
		Reference accuracy	*1
		Temperature coefficient	*1
		Cold junction compensation error	±1.2°C *2 *3
		Input disconnection detection current	Approx. 0.1 μA
Warm-up period	45 minutes	**Conversion time**	60 ms/Unit
Dimensions	12 (W) x 100 (H) x 71 (D)	**Isolation method**	Between the input and the NX bus: Power = Transformer, Signal = Digital isolator Between inputs: Power = Transformer, Signal = Digital isolator
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)	**Dielectric strength**	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
I/O power supply method	No supply	**Current capacity of I/O power supply terminal**	Without I/O power supply terminals
NX Unit power consumption	• Connected to a CPU Unit 0.95 W max. • Connected to a Communications Coupler Unit 0.80 W max.	**Current consumption from I/O power supply**	No consumption
Weight	70 g max.		
Installation orientation and restrictions	Installation orientation: • Connected to a CPU Unit: Possible in upright installation. • Connected to a Communications Coupler Unit: Possible in 6 orientations. Restrictions: The cold junction compensation error is restricted according to the installation orientation and the power consumption of adjacent Units. Refer to *Cold Junction Compensation Error Specifications for Units That Take a Thermocouple Input Type*.		
Terminal connection diagram	Temperature Input Unit NX-TS2104 A1 — B1 NC NC NC NC NC NC NC NC TC2+ TC2− CJ1+ CJ1− Cold junction sensor * Do not touch or remove. TC1+ TC1− Thermocouple input NC NC A8 — B8		

*1. Refer to *Reference Accuracy and Temperature Coefficient According to the Input Type and Measurement Temperature*.
*2. The overall accuracy is guaranteed for a set consisting of a cold junction sensor that is mounted on the terminal block and a Temperature Input Unit. Be sure to use the terminal block and the Temperature Input Unit together. A calibration control number is both displayed on the terminal block and the Unit. Make sure to return the terminal block (including a cold junction sensor mounted) and the Unit together for repair.
*3. Refer to *Cold Junction Compensation Error Specifications for Units That Take a Thermocouple Input Type* for the specifications for each set of operating conditions.

Temperature Input Unit (Resistance Thermometer Input type) 2 points NX-TS2201

|			
Unit name	Temperature Input Unit (resistance thermometer input type)	**Model**	NX-TS2201
Number of points	2 points	**External connection terminals**	Screwless clamping terminal block (16 terminals)
I/O refreshing method	Free-Run refreshing		
Indicator	TS indicator TS2201 ■TS	**Temperature sensor**	Pt100 (three-wire)/Pt1000 (three-wire)
		Input conversion range	±20°C of the input range
		Input detection current	Approx. 0.25 mA
		Resolution	0.1°C max.
		Reference accuracy	*
		Temperature coefficient	*
		Effect of conductor resistance	0.06°C/Ω max. (also 20 Ω max.)
Warm-up period	10 minutes	**Conversion time**	250 ms/Unit
Dimensions	12 (W) x 100 (H) x 71 (D)	**Isolation method**	Between the input and the NX bus: Power = Transformer, Signal = Photocoupler Between inputs: Power = Transformer, Signal = Photocoupler
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)	**Dielectric strength**	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
I/O power supply method	No supply	**Current capacity of I/O power supply terminal**	Without I/O power supply terminals
NX Unit power consumption	• Connected to a CPU Unit 1.25 W max. • Connected to a Communications Coupler Unit 0.90 W max.	**Current consumption from I/O power supply**	No consumption
Weight	70 g max.		
Installation orientation and restrictions	Installation orientation: • Connected to a CPU Unit: Possible in upright installation. • Connected to a Communications Coupler Unit: Possible in 6 orientations. Restrictions: No restrictions		
Terminal connection diagram	Temperature Input Unit NX-TS2201 A1 — B1 NC	NC NC	NC NC	NC NC	NC A2	B2 NC	B2 A1	B1 NC	B1 A8 — B8 A B B Resistance thermometer input		

* Refer to *Reference Accuracy and Temperature Coefficient According to the Input Type and Measurement Temperature.*

Temperature Input Unit (Resistance Thermometer Input type) 2 points NX-TS2202

Unit name	Temperature Input Unit (resistance thermometer input type)	Model	NX-TS2202
Number of points	2 points	External connection terminals	Screwless clamping terminal block (16 terminals)
I/O refreshing method	Free-Run refreshing		

Indicator	TS indicator **TS2202** ■ TS	Temperature sensor	Pt100 (three-wire)
		Input conversion range	±20°C of the input range
		Input detection current	Approx. 0.25 mA
		Resolution	0.01°C max.
		Reference accuracy	*
		Temperature coefficient	*
		Effect of conductor resistance	0.06°C/Ω max. (also 20 Ω max.)

| Warm-up period	30 minutes	Conversion time	10 ms/Unit
Dimensions	12 (W) x 100 (H) x 71 (D)	Isolation method	Between the input and the NX bus: Power = Transformer, Signal = Digital isolator Between inputs: Power = Transformer, Signal = Digital isolator
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)	Dielectric strength	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
I/O power supply method	No supply	Current capacity of I/O power supply terminal	Without I/O power supply terminals

NX Unit power consumption	• Connected to a CPU Unit
	  1.15 W max.
	• Connected to a Communications Coupler Unit
	  0.75 W max.
		Current consumption from I/O power supply	No consumption

Weight	70 g max.		
Installation orientation and restrictions	Installation orientation: • Connected to a CPU Unit: Possible in upright installation. • Connected to a Communications Coupler Unit: Possible in 6 orientations. Restrictions: No restrictions		
Terminal connection diagram			

* Refer to *Reference Accuracy and Temperature Coefficient According to the Input Type and Measurement Temperature.*

Temperature Input Unit (Resistance Thermometer Input type) 2 points NX-TS2204

Unit name	Temperature Input Unit (resistance thermometer input type)	Model	NX-TS2204
Number of points	2 points	External connection terminals	Screwless clamping terminal block (16 terminals)
I/O refreshing method	Free-Run refreshing		
Indicator	TS indicator **TS2204** ■TS	Temperature sensor	Pt100 (three-wire)/Pt1000 (three-wire)
		Input conversion range	±20°C of the input range
		Input detection current	Approx. 0.25 mA
		Resolution	0.001°C max.
		Reference accuracy	*
		Temperature coefficient	*
		Effect of conductor resistance	0.06°C/Ω max. (also 20 Ω max.)
Warm-up period	30 minutes	Conversion time	60 ms/Unit
Dimensions	12 (W) x 100 (H) x 71 (D)	Isolation method	Between the input and the NX bus: Power = Transformer, Signal = Digital isolator Between inputs: Power = Transformer, Signal = Digital isolator
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)	Dielectric strength	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
I/O power supply method	No supply	Current capacity of I/O power supply terminal	Without I/O power supply terminals
NX Unit power consumption	• Connected to a CPU Unit 0.90 W max. • Connected to a Communications Coupler Unit 0.75 W max.	Current consumption from I/O power supply	No consumption
Weight	70 g max.		
Installation orientation and restrictions	Installation orientation: • Connected to a CPU Unit: Possible in upright installation. • Connected to a Communications Coupler Unit: Possible in 6 orientations. Restrictions: No restrictions		
Terminal connection diagram			

* Refer to *Reference Accuracy and Temperature Coefficient According to the Input Type and Measurement Temperature.*

Temperature Input Unit (Thermocouple Input type) 4 points NX-TS3101

Unit name	Temperature Input Unit (thermocouple input type)	Model	NX-TS3101
Number of points	4 points	External connection terminals	Screwless clamping terminal block (16 terminals x 2)
I/O refreshing method	Free-Run refreshing		
Indicators	TS indicator **TS3101** ■TS	Temperature sensor	K, J, T, E, L, U, N, R, S, B, WRe5-26, PLII
		Input conversion range	±20°C of the input range
		Absolute maximum rating	±130 mV
		Input impedance	20 kΩ min.
		Resolution	0.1°C max. *1
		Reference accuracy	*2
		Temperature coefficient	*2
		Cold junction compensation error	±1.2°C *3 *4
		Input disconnection detection current	Approx. 0.1µA
Warm-up period	30 minutes	Conversion time	250 ms/Unit
Dimensions	24 (W) x 100 (H) x 71 (D)	Isolation method	Between the input and the NX bus: Power = Transformer, Signal = Photocoupler Between inputs: Power = Transformer, Signal = Photocoupler
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)	Dielectric strength	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
I/O power supply method	No supply	Current capacity of I/O power supply terminal	Without I/O power supply terminals
NX Unit power consumption	• Connected to a CPU Unit 1.75 W max. • Connected to a Communications Coupler Unit 1.30 W max.	Current consumption from I/O power supply	No consumption
Weight	140 g max.		
Installation orientation and restrictions	Installation orientation: • Connected to a CPU Unit: Possible in upright installation. • Connected to a Communications Coupler Unit: Possible in 6 orientations. Restrictions: The cold junction compensation error is restricted according to the installation orientation and the power consumption of adjacent Units. Refer to *Cold Junction Compensation Error Specifications for Units That Take a Thermocouple Input Type*.		
Terminal connection diagram			

Terminal connection diagram:

Temperature Input Unit NX-TS3101

A1		B1 C1		D1
NC	NC	NC	NC	
NC	NC	NC	NC	
NC	NC	NC	NC	
NC	NC	NC	NC	
TC2+	TC2−	TC4+	TC4−	
CJ1+	CJ1−	CJ2+	CJ2−	
TC1+	TC1−	TC3+	TC3−	
NC	NC	NC	NC	
A8		B8 C8		D8

Cold junction sensor
* Do not touch or remove.

Thermocouple input

*1. The resolution is 0.2°C max. when the input type is R, S, or W.

*2. Refer to *Reference Accuracy and Temperature Coefficient According to the Input Type and Measurement Temperature*.

*3. The overall accuracy is guaranteed for a set consisting of a cold junction sensor that is mounted on the terminal block and a Temperature Input Unit. Be sure to use the terminal block and the Temperature Input Unit together. A calibration control number is both displayed on the terminal block and the Unit. Make sure to return the terminal block (including a cold junction sensor mounted) and the Unit together for repair.

*4. Refer to *Cold Junction Compensation Error Specifications for Units That Take a Thermocouple Input Type* for the specifications for each set of operating conditions.

## Temperature Input Unit (Thermocouple Input type) 4 points NX-TS3102

Unit name	Temperature Input Unit (thermocouple input type)	Model	NX-TS3102
Number of points	4 points	External connection terminals	Screwless clamping terminal block (16 terminals x 2)
I/O refreshing method	Free-Run refreshing		
Indicators	TS indicator **TS3102** ■TS	Temperature sensor	K, J, T, E, L, U, N, R, S, WRe5-26, PLII
		Input conversion range	±20°C of the input range
		Absolute maximum rating	±130 mV
		Input impedance	20 kΩ min.
		Resolution	0.01°C max.
		Reference accuracy	*1
		Temperature coefficient	*1
		Cold junction compensation error	±1.2°C *2 *3
		Input disconnection detection current	Approx. 0.1 μA
Warm-up period	45 minutes	Conversion time	10 ms/Unit
Dimensions	24 (W) x 100 (H) x 71 (D)	Isolation method	Between the input and the NX bus: Power = Transformer, Signal = Digital isolator Between inputs: Power = Transformer, Signal = Digital isolator
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)	Dielectric strength	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
I/O power supply method	No supply	Current capacity of I/O power supply terminal	Without I/O power supply terminals
NX Unit power consumption	• Connected to a CPU Unit 1.55 W max. • Connected to a Communications Coupler Unit 1.10 W max.	Current consumption from I/O power supply	No consumption
Weight	140 g max.		
Installation orientation and restrictions	Installation orientation: • Connected to a CPU Unit: Possible in upright installation. • Connected to a Communications Coupler Unit: Possible in 6 orientations. Restrictions: The cold junction compensation error is restricted according to the installation orientation and the power consumption of adjacent Units. Refer to *Cold Junction Compensation Error Specifications for Units That Take a Thermocouple Input Type*.		
Terminal connection diagram	Temperature Input Unit NX-TS3102 A1　　　B1 C1　　　D1 NC NC NC NC NC NC NC NC NC NC NC NC NC NC NC NC TC2+ TC2− TC4+ TC4− CJ1+ CJ1− CJ2+ CJ2− TC1+ TC1− TC3+ TC3− NC NC NC NC A8　　　B8 C8　　　D8 Cold junction sensor * Do not touch or remove. Thermocouple input		

*1. Refer to *Reference Accuracy and Temperature Coefficient According to the Input Type and Measurement Temperature*.
*2. The overall accuracy is guaranteed for a set consisting of a cold junction sensor that is mounted on the terminal block and a Temperature Input Unit. Be sure to use the terminal block and the Temperature Input Unit together. A calibration control number is both displayed on the terminal block and the Unit. Make sure to return the terminal block (including a cold junction sensor mounted) and the Unit together for repair.
*3. Refer to *Cold Junction Compensation Error Specifications for Units That Take a Thermocouple Input Type* for the specifications for each set of operating conditions.

## Temperature Input Unit (Thermocouple Input type) 4 points NX-TS3104

Unit name	Temperature Input Unit (thermocouple input type)	Model	NX-TS3104
Number of points	4 points	External connection terminals	Screwless clamping terminal block (16 terminals x 2)
I/O refreshing method	Free-Run refreshing		
Indicators	TS indicator **TS3104** ■TS	Temperature sensor	K, J, T, E, L, U, N, R, S, WRe5-26, PLII
		Input conversion range	±20°C of the input range
		Absolute maximum rating	±130 mV
		Input impedance	20 kΩ min.
		Resolution	0.001°C max.
		Reference accuracy	*1
		Temperature coefficient	*1
		Cold junction compensation error	±1.2°C *2 *3
		Input disconnection detection current	Approx. 0.1 μA
Warm-up period	45 minutes	Conversion time	60 ms/Unit
Dimensions	24 (W) x 100 (H) x 71 (D)	Isolation method	Between the input and the NX bus: Power = Transformer, Signal = Digital isolator Between inputs: Power = Transformer, Signal = Digital isolator
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)	Dielectric strength	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
I/O power supply method	No supply	Current capacity of I/O power supply terminal	Without I/O power supply terminals
NX Unit power consumption	• Connected to a CPU Unit 1.45 W max. • Connected to a Communications Coupler Unit 1.10 W max.	Current consumption from I/O power supply	No consumption
Weight	140 g max.		
Installation orientation and restrictions	Installation orientation: • Connected to a CPU Unit: Possible in upright installation. • Connected to a Communications Coupler Unit: Possible in 6 orientations. Restrictions: The cold junction compensation error is restricted according to the installation orientation and the power consumption of adjacent Units. Refer to *Cold Junction Compensation Error Specifications for Units That Take a Thermocouple Input Type*.		
Terminal connection diagram			

Temperature Input Unit NX-TS3104

A1		B1 C1		D1
NC	NC	NC	NC
NC	NC	NC	NC
NC	NC	NC	NC
NC	NC	NC	NC
TC2+	TC2−	TC4+	TC4−
CJ1+	CJ1−	CJ2+	CJ2−
TC1+	TC1−	TC3+	TC3−
NC	NC	NC	NC

A8 B8 C8 D8

Cold junction sensor
* Do not touch or remove.

Thermocouple input

*1. Refer to *Reference Accuracy and Temperature Coefficient According to the Input Type and Measurement Temperature*.
*2. The overall accuracy is guaranteed for a set consisting of a cold junction sensor that is mounted on the terminal block and a Temperature Input Unit. Be sure to use the terminal block and the Temperature Input Unit together. A calibration control number is both displayed on the terminal block and the Unit. Make sure to return the terminal block (including a cold junction sensor mounted) and the Unit together for repair.
*3. Refer to *Cold Junction Compensation Error Specifications for Units That Take a Thermocouple Input Type* for the specifications for each set of operating conditions.

Temperature Input Unit (Resistance Thermometer Input type) 4 points NX-TS3201

Unit name	Temperature Input Unit (resistance thermometer input type)	Model	NX-TS3201
Number of points	4 points	External connection terminals	Screwless clamping terminal block (16 Terminals x 2)
I/O refreshing method	Free-Run refreshing		

Indicator	TS indicator	Temperature sensor	Pt100 (three-wire)/Pt1000 (three-wire)
	TS3201 ■TS	Input conversion range	±20°C of the input range
		Input detection current	Approx. 0.25 mA
		Resolution	0.1°C max.
		Reference accuracy	*
		Temperature coefficient	*
		Effect of conductor resistance	0.06°C/Ω max. (also 20 Ω max.)

| Warm-up period	10 minutes	Conversion time	250 ms/Unit
Dimensions	24 (W) x 100 (H) x 71 (D)	Isolation method	Between the input and the NX bus: Power = Transformer, Signal = Photocoupler Between inputs: Power = Transformer, Signal = Photocoupler
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)	Dielectric strength	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
I/O power supply method	No supply	Current capacity of I/O power supply terminal	Without I/O power supply terminals
NX Unit power consumption	• Connected to a CPU Unit 1.75 W max. • Connected to a Communications Coupler Unit 1.30 W max.	Current consumption from I/O power supply	No consumption
Weight	140 g max.		
Installation orientation and restrictions	Installation orientation: • Connected to a CPU Unit: Possible in upright installation. • Connected to a Communications Coupler Unit: Possible in 6 orientations. Restrictions: No restrictions		
Terminal connection diagram			

* Refer to *Reference Accuracy and Temperature Coefficient According to the Input Type and Measurement Temperature*.

Temperature Input Unit (Resistance Thermometer Input type) 4 points NX-TS3202

Unit name	Temperature Input Unit (resistance thermometer input type)	Model	NX-TS3202
Number of points	4 points	External connection terminals	Screwless clamping terminal block (16 terminals x 2)
I/O refreshing method	Free-Run refreshing		

	TS indicator	Temperature sensor	Pt100 (three-wire)
	TS3202 ■TS	Input conversion range	±20°C of the input range
		Input detection current	Approx. 0.25 mA
		Resolution	0.01°C max.
Indicator		Reference accuracy	*
		Temperature coefficient	*
		Effect of conductor resistance	0.06°C/Ω max. (also 20 Ω max.)

Warm-up period	30 minutes	Conversion time	10 ms/Unit
Dimensions	24 (W) x 100 (H) x 71 (D)	Isolation method	Between the input and the NX bus: Power = Transformer, Signal = Digital isolator Between inputs: Power = Transformer, Signal = Digital isolator
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)	Dielectric strength	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
I/O power supply method	No supply	Current capacity of I/O power supply terminal	Without I/O power supply terminals
NX Unit power consumption	• Connected to a CPU Unit 1.50 W max. • Connected to a Communications Coupler Unit 1.05 W max.	Current consumption from I/O power supply	No consumption
Weight	130 g max.		
Installation orientation and restrictions	Installation orientation: • Connected to a CPU Unit: Possible in upright installation. • Connected to a Communications Coupler Unit: Possible in 6 orientations. Restrictions: No restrictions		
Terminal connection diagram			

Temperature Input Unit
NX-TS3202

A1   B1 C1   D1

NC	NC	NC	NC
NC	NC	NC	NC
NC	NC	NC	NC
NC	NC	NC	NC
A2	B2	A4	B4
NC	B2	NC	B4
A1	B1	A3	B3
NC	B1	NC	B3

A8   B8 C8   D8

A
B
B

Resistance thermometer input

* Refer to *Reference Accuracy and Temperature Coefficient According to the Input Type and Measurement Temperature*.

Temperature Input Unit (Resistance Thermometer Input type) 4 points NX-TS3204

Unit name	Temperature Input Unit (resistance thermometer input type)	Model	NX-TS3204
Number of points	4 points	External connection terminals	Screwless clamping terminal block (16 terminals x 2)
I/O refreshing method	Free-Run refreshing		
Indicator	TS indicator **TS3204** ■TS	Temperature sensor	Pt100 (three-wire)/Pt1000 (three-wire)
		Input conversion range	±20°C of the input range
		Input detection current	Approx. 0.25 mA
		Resolution	0.001°C max.
		Reference accuracy	*
		Temperature coefficient	*
		Effect of conductor resistance	0.06°C/Ω max. (also 20 Ω max.)
Warm-up period	30 minutes	Conversion time	60 ms/Unit
Dimensions	24 (W) x 100 (H) x 71 (D)	Isolation method	Between the input and the NX bus: Power = Transformer, Signal = Digital isolator Between inputs: Power = Transformer, Signal = Digital isolator
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)	Dielectric strength	510 VAC between isolated circuits for 1 minute at a leakage current of 5 mA max.
I/O power supply method	No supply	Current capacity of I/O power supply terminal	Without I/O power supply terminals
NX Unit power consumption	• Connected to a CPU Unit 1.45 W max. • Connected to a Communications Coupler Unit 1.05 W max.	Current consumption from I/O power supply	No consumption
Weight	130 g max.		
Installation orientation and restrictions	Installation orientation: • Connected to a CPU Unit: Possible in upright installation. • Connected to a Communications Coupler Unit: Possible in 6 orientations. Restrictions: No restrictions		
Terminal connection diagram			

Temperature Input Unit NX-TS3204

A1		B1 C1		D1
NC	NC	NC	NC
NC	NC	NC	NC
NC	NC	NC	NC
NC	NC	NC	NC
A2	B2	A4	B4
NC	B2	NC	B4
A1	B1	A3	B3
NC	B1	NC	B3

A8 B8 C8 D8

Resistance thermometer input

* Refer to *Reference Accuracy and Temperature Coefficient According to the Input Type and Measurement Temperature*.

• **Reference accuracy and temperature coefficient according to the input type and measurement temperature *1**

For NX-TS☐☐02/TS☐☐04

| Conversion time | Input type | | Measurement temperature (°C) | Reference accuracy °C (%) *3 | Temperature coefficient °C/°C *4 (ppm/°C *5) |
	Input type *2	Temperature range (°C)			
10/60ms	K	-200 to 1300	Same as the left	±0.75 (±0.05%)	±0.08 (±50 ppm/°C)
	K	-20 to 600 (High Resolution)	Same as the left	±0.30 (±0.05%)	±0.03 (±48 ppm/°C)
	J	-200 to 1200	-200 to 0	±0.70 (±0.05%)	±0.13 (±96 ppm/°C)
			0 to 1200		±0.06 (±42 ppm/°C)
	J	-20 to 600 (High Resolution)	Same as the left	±0.30 (±0.05%)	±0.04 (±72 ppm/°C)
	T	-200 to 400	-200 to -180	±1.30 (±0.22%)	±0.05 (±75 ppm/°C)
			-180 to 0	±0.70 (±0.12%)	
			0 to 400	±0.33 (±0.055%)	
	E	-200 to 1000	-200 to 0	±0.60 (±0.05%)	±0.12 (±100 ppm/°C)
			0 to 1000		±0.06 (±50 ppm/°C)
	L	-200 to 900	Same as the left	±0.50 (±0.05%)	±0.04 (±40 ppm/°C)
	U	-200 to 600	-200 to -100	±0.70 (±0.09%)	±0.06 (±75 ppm/°C)
			-100 to 0	±0.50 (±0.07%)	
			0 to 600	±0.40 (±0.05%)	
	N	-200 to 1300	-200 to -150	±1.60 (±0.11%)	±0.11 (±70 ppm/°C)
			-150 to -100	±0.75 (±0.05%)	
			-100 to 1300		±0.08 (±50 ppm/°C)
	R	-50 to 1700	-50 to 0	±3.20 (±0.19%)	±0.13 (±77 ppm/°C)
			0 to 100	±2.50 (±0.15%)	±0.11 (±60 ppm/°C)
			100 to 1700	±1.75 (±0.10%)	
	S	-50 to 1700	-50 to 0	±3.20 (±0.19%)	±0.13 (±77 ppm/°C)
			0 to 100	±2.50 (±0.15%)	±0.11 (±60 ppm/°C)
			100 to 1700	±1.75 (±0.10%)	
	WRe5-26	0 to 2300	0 to 1500	±1.15 (±0.05%)	±0.13 (±58 ppm/°C)
			1500 to 2200		±0.21 (±91 ppm/°C)
			2200 to 2300	±1.40 (±0.07%)	
	PL II	0 to 1300	Same as the left	±0.65 (±0.05%)	±0.07 (±57 ppm/°C)
	Pt100	-200 to 850	-200 to -50	±0.50 (±0.05%)	±0.08 (±78 ppm/°C)
			-50 to 150	±0.21 (±0.02%)	±0.03 (±29 ppm/°C)
			150 to 850	±0.50 (±0.05%)	±0.08 (±78 ppm/°C)
	Pt1000	-200 to 850	Same as the left	±0.50 (±0.05%)	±0.09 (±85 ppm/°C)

For NX-TS☐☐01

Conversion time	Input type		Measurement temperature (°C)	Reference accuracy °C (%) *3	Temperature coefficient °C/°C *4 (ppm/°C *5)
	Input type	Temperature range (°C)			
250 ms	K	-200 to 1300	-200 to -100	±1.5 (±0.1%)	±0.15 (±100 ppm/°C)
			-100 to 400		±0.30 (±200 ppm/°C)
			400 to 1300		±0.38 (±250 ppm/°C)
	J	-200 to 1200	-200 to 400	±1.4 (±0.1%)	±0.14 (±100 ppm/°C)
			400 to 900	±1.2 (±0.09%)	±0.28 (±200 ppm/°C)
			900 to 1200		±0.35 (±250 ppm/°C)
	T	-200 to 400	-200 to -100	±1.2 (±0.2%)	±0.30 (±500 ppm/°C)
			-100 to 400		±0.12 (±200 ppm/°C)
	E	-200 to 1000	-200 to 400	±1.2 (±0.1%)	±0.12 (±100 ppm/°C)
			400 to 700	±2.0 (±0.17%)	±0.24 (±200 ppm/°C)
			700 to 1000		±0.30 (±250 ppm/°C)
	L	-200 to 900	-200 to 300	±1.1 (±0.1%)	±0.11 (±100 ppm/°C)
			300 to 700	±2.2 (±0.2%)	±0.22 (±200 ppm/°C)
			700 to 900		±0.28 (±250 ppm/°C)
	U	-200 to 600	-200 to 400	±1.2 (±0.15%)	±0.12 (±150 ppm/°C)
			400 to 600	±1.0 (±0.13%)	
	N	-200 to 1300	-200 to 400	±1.5 (±0.1%)	±0.30 (±200 ppm/°C)
			400 to 1000		
			1000 to 1300		±0.38 (±250 ppm/°C)
	R	-50 to 1700	-50 to 500	±1.75 (±0.1%)	±0.44 (±250 ppm/°C)
			500 to 1200	±2.5 (±0.15%)	
			1200 to 1700		
	S	-50 to 1700	-50 to 600	±1.75 (±0.1%)	±0.44 (±250 ppm/°C)
			600 to 1100	±2.5 (±0.15%)	
			1100 to 1700		
	B	0 to 1800	0.0 to 400.0	Reference accuracy does not apply	Reference accuracy does not apply
			400 to 1200	±3.6 (±0.2%)	±0.45 (±250 ppm/°C)
			1200 to 1800	±5.0 (±0.28%)	±0.54 (±300 ppm/°C)
	WRe5-26	0 to 2300	0 to 300	±1.15 (±0.05%)	±0.46 (±200 ppm/°C)
			300 to 800	±2.3 (±0.1%)	
			800 to 1500	±3.0 (±0.13%)	
			1500 to 2300		±0.691 (±300 ppm/°C)
	PLII	0 to 1300	0 to 400	±1.3 (±0.1%)	±0.23 (±200 ppm/°C)
			400 to 800	±2.0 (±0.15%)	±0.39 (±300 ppm/°C)
			800 to 1300		±0.65 (±500 ppm/°C)
	Pt100	-200 to 850	-200 to 300	±1.0 (±0.1%)	±0.1 (±100 ppm/°C)
			300 to 700	±2.0 (±0.2%)	±0.2 (±200 ppm/°C)
			700 to 850	±2.5 (±0.25%)	±0.25 (±250 ppm/°C)
	Pt1000	-200 to 850	-200 to 300	±1.0 (±0.1%)	±0.1 (±100 ppm/°C)
			300 to 700	±2.0 (±0.2%)	±0.2 (±200 ppm/°C)
			700 to 850	±2.5 (±0.25%)	±0.25 (±250 ppm/°C)

*1. To convert the temperature unit from Celsius to Fahrenheit, use the following equation.
Fahrenheit temperature (°F) = Celsius temperature (°C) x 1.8 + 32
*2. If there is more than one input range for the same input type, the one with narrower input range has higher resolution.
*3. For a thermocouple input type Temperature Input Unit, the overall accuracy is guaranteed for a set consisting of a cold junction sensor that is mounted on the terminal block and a Temperature Input Unit. Be sure to use the terminal block and Temperature Input Unit with the same calibration control number together. For the 24 mm wide model, also be sure the left and right terminal blocks are correctly attached.

*4. An error for a measured value when the ambient temperature changes by 1°C.
The following formula is used to calculate the error of the measured value.
Overall accuracy = Reference accuracy + Temperature characteristic x Change in the ambient temperature + Cold junction compensation error
(Calculation example)
Conditions

Item	Description
Ambient temperature	30°C
Measured value	100°C
NX Unit	NX-TS2101
Thermocouple	K thermocouple

The characteristic values are formulated from the data sheet or reference accuracy and temperature coefficient table under the above conditions

Item	Description
Reference accuracy	-100 to 400°C: ±1.5°C
Temperature coefficient	-100 to 400°C: ±0.30°C/°C
Change in the ambient temperature	25°C -> 30°C 5 deg
Cold junction compensation error	±1.2°C

Therefore,
Overall accuracy = Reference accuracy + Temperature characteristic x Change in the ambient temperature + Cold junction compensation error
= ±1.5°C + (±0.30°C/°C) x 5 deg + ±1.2°C
= ±4.2°C

*5. The ppm value is for the full scale of temperature range.

• Cold Junction Compensation Error Specifications for Units That Take a Thermocouple Input Type

The cold junction compensation error for Units that take a thermocouple input type is restricted as follows according to the installation orientation and the power consumption of adjacent Units [*].

(a) For upright installation, when the power consumption is 1.5 W or less for both the left and right adjacent Units

The cold junction compensation error is ±1.2°C.
However, there are exceptions depending on the input type and temperature. Those conditions and the cold junction compensation error are as in the table below.

Input type and temperature range	Cold junction compensation error
T below -90°C	±3.0°C
J, E, K and N below -100°C	
U, L and PLII	
R and S below 200°C	
B below 400°C	Not guaranteed
W	±3.0°C

(b) When the power consumption of either the left or the right adjacent Unit is more than 1.5 W but less than 3.9 W. Or for any installation other than upright, when the power consumption of both the left and right adjacent Units is less than 3.9 W

The cold junction compensation error is ±4.0°C.
However, there are exceptions depending on the input type and temperature. Those conditions and the cold junction compensation error are as in the table below.

Input type and temperature range	Cold junction compensation error
T below -90°C	±7.0°C
J, E, K and N below -100°C	
U, L and PLII	
R and S below 200°C	
B below 400°C	Not guaranteed
W	±9.0°C

(c) When the power consumption exceeds 3.9 W for either the left or right adjacent Unit

Do not use the above condition (c) because the cold junction compensation error is not guaranteed in this condition.

* The power consumption of adjacent Units is the total of the following values.
The power consumption of the NX Unit power supply and I/O power supply for the NX Units adjacent to the Temperature Input Unit. If the adjacent Unit is an Input Unit, it is the total power consumption according to the input current.

Version Information

Connected to a CPU Unit

Refer to the user's manual for the CPU Unit for details on the CPU Units to which NX Units can be connected.

NX Unit		Corresponding version *	
Model	Unit Version	CPU Unit	Sysmac Studio
NX-TS2101	Ver.1.0	Ver.1.13 or later	Ver.1.17 or higher
NX-TS2101	Ver.1.1	Ver.1.13 or later	Ver.1.17 or higher
NX-TS2102	Ver.1.1	Ver.1.13 or later	Ver.1.17 or higher
NX-TS2104	Ver.1.1	Ver.1.13 or later	Ver.1.17 or higher
NX-TS2201	Ver.1.0	Ver.1.13 or later	Ver.1.17 or higher
NX-TS2201	Ver.1.1	Ver.1.13 or later	Ver.1.17 or higher
NX-TS2202	Ver.1.1	Ver.1.13 or later	Ver.1.17 or higher
NX-TS2204	Ver.1.1	Ver.1.13 or later	Ver.1.17 or higher
NX-TS3101	Ver.1.0	Ver.1.13 or later	Ver.1.17 or higher
NX-TS3101	Ver.1.1	Ver.1.13 or later	Ver.1.17 or higher
NX-TS3102	Ver.1.1	Ver.1.13 or later	Ver.1.17 or higher
NX-TS3104	Ver.1.1	Ver.1.13 or later	Ver.1.17 or higher
NX-TS3201	Ver.1.0	Ver.1.13 or later	Ver.1.17 or higher
NX-TS3201	Ver.1.1	Ver.1.13 or later	Ver.1.17 or higher
NX-TS3202	Ver.1.1	Ver.1.13 or later	Ver.1.17 or higher
NX-TS3204	Ver.1.1	Ver.1.13 or later	Ver.1.17 or higher

* Some Units do not have all of the versions given in the above table. If a Unit does not have the specified version, support is provided by the oldest available version after the specified version. Refer to the user's manuals for the specific Units for the relation between models and versions.

Connected to a Communications Coupler Unit

NX Unit		Corresponding version *				
		EtherCAT			Ethernet/IP	
Model	Unit Version	Communications Coupler Unit	NJ/NX-series CPU Unit or NY-series Industrial PC	Sysmac Studio	Communications Coupler Unit	Sysmac Studio
NX-TS2101	Ver.1.0	Ver.1.0 or later	Ver.1.05 or later	Ver.1.06 or higher	Ver.1.0 or later	Ver.1.10 or higher
NX-TS2101	Ver.1.1	Ver.1.0 or later	Ver.1.05 or later	Ver.1.08 or higher	Ver.1.0 or later	Ver.1.10 or higher
NX-TS2102	Ver.1.1	Ver.1.0 or later	Ver.1.05 or later	Ver.1.08 or higher	Ver.1.0 or later	Ver.1.10 or higher
NX-TS2104	Ver.1.1	Ver.1.0 or later	Ver.1.05 or later	Ver.1.08 or higher	Ver.1.0 or later	Ver.1.10 or higher
NX-TS2201	Ver.1.0	Ver.1.0 or later	Ver.1.05 or later	Ver.1.06 or higher	Ver.1.0 or later	Ver.1.10 or higher
NX-TS2201	Ver.1.1	Ver.1.0 or later	Ver.1.05 or later	Ver.1.08 or higher	Ver.1.0 or later	Ver.1.10 or higher
NX-TS2202	Ver.1.1	Ver.1.0 or later	Ver.1.05 or later	Ver.1.08 or higher	Ver.1.0 or later	Ver.1.10 or higher
NX-TS2204	Ver.1.1	Ver.1.0 or later	Ver.1.05 or later	Ver.1.08 or higher	Ver.1.0 or later	Ver.1.10 or higher
NX-TS3101	Ver.1.0	Ver.1.0 or later	Ver.1.05 or later	Ver.1.06 or higher	Ver.1.0 or later	Ver.1.10 or higher
NX-TS3101	Ver.1.1	Ver.1.0 or later	Ver.1.05 or later	Ver.1.08 or higher	Ver.1.0 or later	Ver.1.10 or higher
NX-TS3102	Ver.1.1	Ver.1.0 or later	Ver.1.05 or later	Ver.1.08 or higher	Ver.1.0 or later	Ver.1.10 or higher
NX-TS3104	Ver.1.1	Ver.1.0 or later	Ver.1.05 or later	Ver.1.08 or higher	Ver.1.0 or later	Ver.1.10 or higher
NX-TS3201	Ver.1.0	Ver.1.0 or later	Ver.1.05 or later	Ver.1.06 or higher	Ver.1.0 or later	Ver.1.10 or higher
NX-TS3201	Ver.1.1	Ver.1.0 or later	Ver.1.05 or later	Ver.1.08 or higher	Ver.1.0 or later	Ver.1.10 or higher
NX-TS3202	Ver.1.1	Ver.1.0 or later	Ver.1.05 or later	Ver.1.08 or higher	Ver.1.0 or later	Ver.1.10 or higher
NX-TS3204	Ver.1.1	Ver.1.0 or later	Ver.1.05 or later	Ver.1.08 or higher	Ver.1.0 or later	Ver.1.10 or higher

* Some Units do not have all of the versions given in the above table. If a Unit does not have the specified version, support is provided by the oldest available version after the specified version. Refer to the user's manuals for the specific Units for the relation between models and versions.

NX-series Heater Burnout Detection Unit
NX-HB

Temperature control with heater burnout detection in conjunction with a temperature input unit and PID instructions

- Reduce the costs for communications programming and other development
- Achieve flexible temperature control

NX-HB3101

Features

- Up to four CT inputs per unit
- Omron's proven heater burnout detection function
- Monitoring of CT currents to detect heater burnouts and SSR failures
- Time-proportional control outputs to drive SSRs
- Control outputs not affected by controller cycle time
- Four control outputs to drive SSRs (100 mA max.)
- Heater burnout detection for a single-phase or three-phase heater
- Detachable front connector with screwless Push-In Plus terminals for easy installation and maintenance

System Configurations

Connected to a CPU Unit

The following figure shows a system configuration when NX Units are connected to an NX-series CPU Unit.

NX-series CPU Unit
NX1P2-□□□□□□□

Additional I/O Power Supply Unit
NX-PF□□□□

Heater Burnout Detection Unit
NX-HB□□□□

Temperature Input Unit
NX-TS□□□□

Support software
(Sysmac Studio)

Unit power supply

Connection to built-in EtherNet/IP™ port

Temperature sensor

I/O power supply

Heater power supply

SSR *

Heater

CT (E54-CT or E54-CT3)

* The SSR is used to turn the heater ON and OFF.

Connected to an EtherCAT Coupler Unit

The following figure shows an example of the system configuration when an EtherCAT Coupler Unit is used as a Communications Coupler Unit.

Support software
(Sysmac Studio)

Connection to peripheral USB port or
built-in EtherNet/IP port on NJ/NX-series
CPU Unit or NY-series Industrial PC *1

.xml

ESI files

EtherCAT master *2
(NJ/NX-series CPU Unit or NY-series Industrial PC)

EtherCAT Coupler Unit
NX-ECC□□□□

Heater Burnout Detection Unit
NX-HB□□□□

Temperature Input Unit
NX-TS□□□□

EtherCAT communications cable

Temperature sensor

Unit power supply
and I/O power supply

Heater power supply

SSR *3

Heater

CT (E54-CT or E54-CT3)

*1. The connection method for the Sysmac Studio depends on the model of the CPU Unit or Industrial PC.
*2. An EtherCAT Slave Terminal cannot be connected to any of the OMRON CJ1W-NC□81/□82 Position Control Units even though they can operate as EtherCAT masters.
*3. The SSR is used to turn the heater ON and OFF.

Note: To check whether NX Units can be connected to your CPU Unit or Communications Coupler Unit, refer to the user's manual for the CPU Unit or Communications Coupler Unit.

Function Specifications

Function	Description
Free-Run Refreshing	With this I/O refreshing method, the refresh cycle of the NX bus and I/O refresh cycles of the NX Units are asynchronous.
CT Allocation	This function is used to assign each CT input to a corresponding control output.
Reading CT Currents	This function reads CT inputs as heater currents or leakage currents.
Heater Burnout Detection	This function detects heater burnouts. A heater burnout is detected if the control output is ON and the heater current is equal to or less than the heater burnout detection current.
SSR Failure Detection	This function detects SSR failures. An SSR failure is detected if the control output is OFF and the leakage current is equal to or greater than the detection current. An SSR failure is a failure that is caused by an SSR short-circuit.
Time-proportional Output	This function controls a control output by using the manipulated variable from the host controller as a duty ratio. You can also specify the minimum pulse widths and execute immediate output commands.
Load Rejection Output Setting	This function performs a preset output operation when the Heater Burnout Detection Unit cannot receive an output set value due to a communications error between the host and the Communications Coupler Unit or due to an error on the NX bus.
Load Short-circuit Protection	This function is used to protect the output circuits of the Heater Burnout Detection Unit when an external device short-circuits. This function is supported only by the NX-HB3201.

Heater Burnout Detection Unit

Heater Burnout Detection Unit (NPN) NX-HB3101

Unit name	Heater Burnout Detection Unit		Model	NX-HB3101
Number of points	4 CT inputs and 4 control outputs		**External connection terminals**	Screwless Clamping Terminal Block (16 terminals)
I/O refreshing method	Free-Run refreshing			
Indicators	TS indicator and output indicators HB3101 ■TS ■1 ■2 ■3 ■4			
CT input section	**CT current input range**	0 to 0.125 A	**Control output section**	**Internal I/O common**	NPN
	Input resistance	Approx. 2.7 Ω		**Control period**	50 to 100,000 ms
	Connectable CTs	E54-CT1 and E54-CT3		**Manipulated variable**	0% to 100%
				Resolution	1 ms
				Rated voltage	12 to 24 V DC
	Maximum heater current	50 A AC		**Operating load voltage range**	10.2 to 28.8 VDC
	Resolution	0.1 A		**Maximum load current**	0.1 A/point, 0.4 A/Unit
	Overall accuracy (25°C)	±5% (full scale) ±1 digit		**Maximum inrush current**	1.0 A/point max., 10 ms
				Leakage current	0.1 mA max.
				Residual voltage	1.5 V max.
	Influence of temperature (0 to 55°C)	±2% (full scale) ±1 digit		**Disconnection/ short-circuit detection**	None
	Conversion time	10 ms		**Protective functions**	None
Dimensions (mm)	12 × 100 × 71 mm (W×H×D)		**Isolation method**	Between control outputs and Internal circuits: Photocoupler isolation No isolation between Internal circuits and CT inputs
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)		**Dielectric strength**	510 VAC between isolated circuits for 1 minute with a leakage current of 5 mA max.
I/O power supply method	Supplied from the NX bus.		**Current capacity of I/O power supply terminals**	IOV: 0.1 A max. per terminal

NX Unit power consumption	• Connected to a CPU Unit
	  1.05 W max.
	• Connected to a Communications Coupler Unit
	  0.75 W max.
			Current consumption from I/O power supply	20 mA max.

Weight	70 g max.			

Circuit configuration	Control outputs Internal circuits IOV1 to IOV4 — Terminal Block OUT1 to OUT4 NX bus connector (left) I/O power supply + I/O power supply − I/O power supply + — NX bus connector (right) I/O power supply − CT inputs CT1+ to CT4+ Terminal Block Approx. 2.7 Ω Amplifier Internal circuits CT1- to CT4- V_{REF} Internal circuit GND
Installation method and restrictions	Installation orientation: • Connected to a CPU Unit: Possible in upright installation. • Connected to a Communications Coupler Unit: Possible in 6 orientations. Restrictions: No restrictions
Terminal connection diagram	Additional I/O Power Supply Unit A1 — B1 IOV / IOV IOG / IOG IOV / IOV IOG / IOG A8 — B8 24 VDC Heater Burnout Detection Unit A1 — B1 CT1+ / CT2+ CT1- / CT2- CT3+ / CT4+ CT3- / CT4- OUT1 / OUT2 IOV1 / IOV2 OUT3 / OUT4 IOV3 / IOV4 A8 — B8 CT SSR

Heater Burnout Detection Unit (PNP) NX-HB3201

Unit name	Heater Burnout Detection Unit		Model	NX-HB3201
Number of points	4 CT inputs and 4 control outputs		**External connection terminals**	Screwless Clamping Terminal Block (16 terminals)
I/O refreshing method	Free-Run refreshing			
Indicators	TS indicator and output indicators HB3201 ■TS ■1 ■2 ■3 ■4			
CT input section	**CT current input range**	0 to 0.125 A	**Control output section**	**Internal I/O common**	PNP
	Input resistance	Approx. 2.7 Ω		**Control period**	50 to 100,000 ms
	Connectable CTs	E54-CT1 and E54-CT3		**Manipulated variable**	0% to 100%
				Resolution	1 ms
				Rated voltage	24 VDC
	Maximum heater current	50 A AC		**Operating load voltage range**	15 to 28.8 VDC
	Resolution	0.1 A		**Maximum load current**	0.1 A/point, 0.4 A/Unit
	Overall accuracy (25°C)	±5% (full scale) ±1 digit		**Maximum inrush current**	1.0 A/point max., 10 ms
				Leakage current	0.1 mA max.
	Influence of temperature (0 to 55°C)	±2% (full scale) ±1 digit		**Residual voltage**	1.5 V max.
				Disconnection/ short-circuit detection	None
	Conversion time	10 ms		**Protective functions**	Provided.
Dimensions (mm)	12 × 100 × 71 mm (W×H×D)		**Isolation method**	Between control outputs and Internal circuits: Photocoupler isolation No isolation between Internal circuits and CT inputs
Insulation resistance	20 MΩ min. between isolated circuits (at 100 VDC)		**Dielectric strength**	510 VAC between isolated circuits for 1 minute with a leakage current of 5 mA max.
I/O power supply method	Supplied from the NX bus.		**Current capacity of I/ O power supply terminals**	IOV: 0.1 A max. per terminal
NX Unit power consumption	• Connected to a CPU Unit 1.05 W max. • Connected to a Communications Coupler Unit 0.75 W max.		**Current consumption from I/O power supply**	20 mA max.
Weight	70 g max.			

Circuit configuration	Control outputs Internal circuits — Short-circuit protection — OUT1 to OUT4 } Terminal Block IOG1 to IOG4 NX bus connector (left) — I/O power supply + / I/O power supply − I/O power supply + / I/O power supply − } NX bus connector (right) CT inputs Terminal Block CT1+ to CT4+ — Approx. 2.7 Ω — Amplifier — Internal circuits Internal circuit GND CT1- to CT4- — V_{REF}
Installation method and restrictions	Installation orientation: • Connected to a CPU Unit: Possible in upright installation. • Connected to a Communications Coupler Unit: Possible in 6 orientations. Restrictions: No restrictions
Terminal connection diagram	Additional I/O Power Supply Unit A1 — IOV / IOV — B1 IOG / IOG IOV / IOV IOG / IOG A8 — B8 24 VDC Heater Burnout Detection Unit A1 — CT1+ / CT2+ — B1 — CT CT1- / CT2- CT3+ / CT4+ CT3- / CT4- OUT1 / OUT2 IOG1 / IOG2 — SSR OUT3 / OUT4 A8 — IOG3 / IOG4 — B8

Version Information

Connected to a CPU Unit

Refer to the user's manual for details on the CPU Units for the CPU Unit to which NX Units can be connected.

NX Unit		Corresponding version *	
Model	Unit version	CPU Unit	Sysmac Studio
NX-HB3101	Ver.1.0	Ver.1.13 or later	Ver.1.17 or higher
NX-HB3201			

* Some Units do not have all of the versions given in the above table. If a Unit does not have the specified version, support is provided by the oldest available version after the specified version. Refer to the user's manuals for the specific Units for the relation between models and versions.

Connected to a Communications Coupler Unit

NX Unit		Corresponding version *				
		EtherCAT			EtherNet/IP	
Model	Unit version	Communications Coupler Unit	NJ/NX-series CPU Unit or NY-series Industrial PC	Sysmac Studio	Communications Coupler Unit	Sysmac Studio
NX-HB3101	Ver.1.0	Ver.1.0 or later	Ver.1.05 or later	Ver.1.16 or higher	Ver.1.0 or later	Ver.1.16 or higher
NX-HB3201						

* Some Units do not have all of the versions given in the above table. If a Unit does not have the specified version, support is provided by the oldest available version after the specified version. Refer to the user's manuals for the specific Units for the relation between models and versions.

Terms and Conditions Agreement