NetManager™ Horizontal Cable Managers



specifications

Horizontal cable managers shall be capable of managing copper or fiber cables. They shall be molded out of plastic and incorporate bend radius control throughout the fingers, pass through holes, and transitions between horizontal and vertical pathways. Front hinged cover shall open 180° in up or down position. They shall mount to any standard EIA 19" rack.



technical information

Dimensions:	NCMH2: 3.47"H x 19.0"W x 9.75"D (88.1 x 482.6 x 247.7mm) NCMHF2: 3.47"H x 19.0"W x 3.75"D (88.1 x 482.6 x 95.3mm) NCMHF1: 1.72"H x 19.0"W x 3.75"D (43.7 x 482.6 x 95.3mm)				
Mounting option:	Mounts to standard EIA 19" rack or 23" rack with optional extender bracket				
Packaging:	Cable management panels include hinged front cover, snap-on rear cover and mounting hardware				
Finger spacing:	3/8" spacing between fingers				
Bend radius: control	1/2" bend radius for fingers, transitions and pass throughs on front 3/8" bend radius for fingers on rear				

key features and benefits

Integral bend radius	Maintains cable bend radii in all cable pathways for high performance copper and fiber applications		
Curved fingers	Separates and organizes Category 5e and Category 6 cable for simple moves, adds and changes		
Cable pass through holes	Provides ease of installation and cable maintenance		
Integral wire retainers	Holds cable in place for easy moves, adds and changes		
Lightweight plastic construction	Provides durability and easy installation		
Hinged front cover	Opens 180° up or down to allow hands-free access to cable		

applications

Designed for Category 5e, Category 6 and fiber cables, the Panduit® NetManager™ Horizontal Cable Managers provide a cost effective solution that organizes, manages, and protects network cabling in telecommunication rooms and data centers. Finger spacing organizes cable as they exit the patch panel and bend radius control helps protect cable from kinks, snags and crushing,

ensuring system performance and reliability. When used with Panduit® Mini-Com® or QuickNet® Patch Panels, Panduit patch cords, vertical managers, and racks, the user receives a complete end-to-end solution that satisfies functional requirements and showcases the network cabling.

2 Rack Space Panel, Front and Rear

3" x 3" front and 2" x 5" rear

NCMH2

2 Rack Space Panel, Front Only

3" x 3" front: NCMHF2

1 Rack Space Panel, Front Only

1.5" x 3" front: NCMHF1

Accessories

Extender bracket, 1 RU: Extender bracket, 2 RU:

Standard 2 Post Racks - 7 Foot

3" channel	
19" mount:	CMR19X84
19" mount:	CMR19X84S
19" mount:	R2P79
19" mount:	R2P^
19" mount:	R2P48
6" channel	
19" mount:	B2P6S

^Add suffix 96 to the end of the part number for 8 foot versions

4 Post Racks, 19" Mount - 7 Foot

23" deep:	R4P23*^
30" deep:	R4P*^
36" deep:	R4P36*^
42" deep:	R4P42*^
* Add "CNI" for Cose Nut Dolla	

^Add suffix 96 to the end of the part number for 8 foot versions

NetRunner™ Vertical Cable Managers

Front and rear	
22 RU, 4" x 5":	WMPV22E
45 RÚ, 4" x 5":	WMPV45E
45 RÚ, 6" x 6":	WMPVHC45E
Front only	
00 DIL 41 EII-	WWWDV/COOK

WMPVF45E WMPVHCF45E NetRunner™ High Capacity Vertical

Front and rear	
45 RU, 6" x 6":	NRV6
45 RÚ, 10" x 6":	NRV10
45 RÚ, 12" x 6":	NRV12
Front only	
45 RU, 6" x 6":	NRVF6
45 RÚ, 10" x 6":	NRVF10
45 RÚ, 12" x 6":	NRVF12
Doors	
6" wide:	NRD6
10" wido.	NDD10

NRD12 12" wide: PatchRunner™ Vertical Cable Managers

Front and rear	
45 RU 6" wide:	PRV6
45 RU 8" wide:	PRV8
45 RU 10" wide:	PRV10
45 RU 12" wide:	PRV12
45 RU 15" wide:	PRV15
Front only	
45 RU 6" wide:	PRVF6
45 RU 8" wide:	PRVF8
45 RU 10" wide:	PRVF10
45 RU 12" wide:	PRVF12
45 RU 15" wide:	PRVF15


Dual Hinged Doors 7 Foot^


6" wide:	PRD6
8" wide:	PRD8
10" wide:	PRD10
12" wide:	PRD12
15" wide:	PRD15

Single Hinged Door

6" wide:	PRSHD6
8" wide:	PRSHD8
12" wide:	PRSHD12
^Add suffix 96 to the end	of the part number
for 8 foot versions.	

NetManager™ Horizontal Cable Managers





CABLE CAPACITY CHART						
MANAGER			Cat (.18	. 5e 37")	Fiber 3mm	
	Front	Back	Front	Back	Front	Back
NCMH2	48	48	72	72	192	192
NCMHF2	48	_	72	_	192	_
NCMHF1	16	_	24	_	72	_

NOTE: For optimal routing of patch cords to left and right of manager, leave middle slot empty.

Dimensions are in inches. [Dimensions in brackets are metric].

WORLDWIDE SUBSIDIARIES AND SALES OFFICES

PANDUIT CANADA Markham, Ontario cs-cdn@panduit.com Phone: 800.777.3300 PANDUIT EUROPE LTD. London, UK cs-emea@panduit.com Phone: 44.20.8601.7200 PANDUIT SINGAPORE PTE. LTD. Republic of Singapore cs-ap@panduit.com Phone: 65.6305.7575

PANDUIT JAPAN Tokyo, Japan cs-japan@panduit.com Phone: 81.3.6863.6000 PANDUIT LATIN AMERICA Jalisco, Mexico cs-la@panduit.com Phone: 52.33.3777.6000 PANDUIT AUSTRALIA PTY. LTD. Victoria, Australia cs-aus@panduit.com Phone: 61.3.9794.9020

For a copy of Panduit product warranties, log on to www.panduit.com/warranty



Visit us at www.panduit.com

Contact Customer Service by email: cs@panduit.com or by phone: 800-777-3300 and reference RKSP03

© 2010 Panduit Corp. ALL RIGHTS RESERVED. **WW-RKSP03** 7/2010

