



Accessories: Legend Plates and Inserts



Plastic With Insert



Laminated Plastic



Metal

Add Catalog Number Suffix To Legend Plate

Legend	Catalog No Suffix
Black Blank (Silver Insert) ^①	BB
Blank/Red Insert ^①	BR
Auto	13
Close	19
Down	17
Down-Off-Up	89
Down-Up	61
Emerg. Stop ^②	27
Fast	09
Forward	07
Fwd.-Auto-Rev.	85
Fwd.-Rev.	57
Hand	12
Hand-Auto	52
Hand-Off-Auto	80
High	24
In	20
Inch	05
Inch-Run	59
In-Out	69
Jog	28
Left	22
Low	25
Manual	14
Manual-Auto	58
Manual-Off-Auto	84
Motor Run	38
Motor Start	37
Off	02
Off-On	50
On	01
On-Off	55
Open	18
Open-Close	60
Open-Off-Close	88
Out	21
Power-Off	39
Power-On	30
Push-To-Test	36
Raise-Lower	68
Reset	15
Reverse	08
Rev.-Fwd.	53
Rev.-Off-Fwd.	81
Right	23
Run	06
Run-Jog	65
Slow	11
Slow-Fast	54
Slow-Stop-Fast	82
Start	03
Start-Stop	56
Stop ^②	04
Stop-Start	51
Test	26
Up	16

Plastic Legend Plate Holder (without Legend Insert)

Insert Size	Catalog No	Price \$
12.5 mm × 27 mm	P22LPSHB	0.90
27 mm × 27 mm	P22LPSHBL	1.20

Blank 27 mm × 27 mm Insert Only^③

Color	Catalog No	Price \$
Silver	3SB1906-2AA	0.90
Red	3SB1906-2XA	0.90

Blank 12.5 mm × 27 mm Insert Only^③

Color	Catalog No	Price \$
Silver	P30LPiBB	0.90
Red	P30LPiBR	0.90

Name Plates for Joy Stick^④

Direction	Description	Catalog No	Price \$
2 Direction	2 direction horizontal	3SB1906-0AU	2.00
	2 direction vertical	3SB1906-0AV	2.00
4 Direction	4 direction	3SB1906-0AW	4.00

Note: For inscription labels and caps see page 515.

①For special engraving, add **Z99** and add **\$3.00** list.

②Red legend plate or red insert for stop and emergency stop are supplied unless otherwise specified.

③For legend on insert replace the last 2 digits with suffix from table.

④Use 3SB1906-2AA inserts (27 mm × 27 mm).

9
Pushbuttons and Pilot Devices