

# 10 Channel, 2-Wire REMOTE CONTROL



# K8023

Control up to 10 devices from a distance using only 2 wires.

#### Features:

- ☑ Microprocessor controlled.
- ☑ Inputs can be push-buttons, switches or open collector outputs from another device.
- I The receiver section provide 10 open collector outputs which allow you to control relays directly.
- ☑ Terminal block connectors for all input and output connections are included.
- ☑ All outputs are provided with LED indication.
- ☑ Can be used with our kits: K8000,K8006,K8046,K8050,...
- ☑ Can be connected to our standard relay card: K6714, K6714-16

#### Specifications:

- 10 open collector outputs 50V/100mA
- Tested to a distance of up to 50m (55 yards) between control- and receiver section.
- Operating voltage: Single 12-15V AC or DC, 300mA.
- Dimensions control pcb (wxdxh): 70x50x16mm (2,7"x2"x0,6").
- Dimensions receiver pcb (wxdxh): 103x50x24mm(4"x2"x1").

Ø

#### 1. Assembly (Skipping this can lead to troubles !)

Ok, so we have your attention. These hints will help you to make this project successful. Read them carefully.

#### 1.1 Make sure you have the right tools:

- A good quality soldering iron (25-40W) with a small tip.
- Wipe it often on a wet sponge or cloth, to keep it clean; then apply solder to the tip, to give it a wet look. This is called 'thinning' and will
  protect the tip, and enables you to make good connections. When solder rolls off the tip, it needs cleaning.
- Thin raisin-core solder. Do not use any flux or grease.
- A diagonal cutter to trim excess wires. To avoid injury when cutting excess leads, hold the lead so they
  cannot fly towards the eyes.
- Needle nose pliers, for bending leads, or to hold components in place.
- Small blade and Phillips screwdrivers. A basic range is fine.

For some projects, a basic multi-meter is required, or might be handy

#### 1.2 Assembly Hints :

- ⇒ Make sure the skill level matches your experience, to avoid disappointments.
- ⇒ Follow the instructions carefully. Read and understand the entire step before you perform each operation.
- ⇒ Perform the assembly in the correct order as stated in this manual
- ⇒ Position all parts on the PCB (Printed Circuit Board) as shown on the drawings.
- $\Rightarrow$  Values on the circuit diagram are subject to changes.
- ⇒ Values in this assembly guide are correct\*
- ⇒ Use the check-boxes to mark your progress.
- $\Rightarrow$  Please read the included information on safety and customer service

\* Typographical inaccuracies excluded. Always look for possible last minute manual updates, indicated as 'NOTE' on a separate leaflet.



Assembly hints

#### 1.3 Soldering Hints :

1- Mount the component against the PCB surface and carefully solder the leads

- 2- Make sure the solder joints are cone-shaped and shiny
- 3- Trim excess leads as close as possible to the solder joint

**REMOVE THEM FROM THE TAPE ONE AT A TIME !** 

#### AXIAL COMPONENTS ARE TAPED IN THE COR-**RECT MOUNTING SEQUENCE!**

lash P You will find the colour code for the resistances and the LEDs in the HALG (general manual) and on our website: http://www.velleman.be/common/service.aspx











#### Construction

velleman"



vellemen'





#### 13. Hook - up & Testing





#### 14. Operation

#### 1. Control section (P8023S):

Both PCBs are connected to each other by means of two wires, VTX+ and VTX-. They supply power to the control board and carry the data signal. This signal contains information regarding the status of the 10 inputs. Filtering and regulating of the power supply is performed by VR2, together with C15, C12, C13 and C14, which also suppress possible oscillation of the voltage regulator.

The micro controller continuously monitors the status of the inputs, and switches T2 according to a custom developed serial protocol. This allows a current to flow in the VTX wires. LD12 also lights allowing you to check the operation of the system.

#### 2. Receiver section (P8023R):

The receiver end also contains a power supply section. Diodes D1 to D4 rectify the incoming power. Voltage regulator VR1 and the surrounding capacitors make sure the control part receives a regulated 10V. From this 10V, R12, ZD1 and C8 derive 5V DC to supply the microcontroller. The actual receiving part consists of D6, D7, R14, R15 and T1. The current variations in the VTX-lines cause a voltage drop over R15, which is filtered by C3 and amplified by T1, before it is fed to the micro controller. Reception is indicated by LD11. The microcontroller analyses the serial signal, and puts the corresponding outputs high or low.

Because the microcontroller cannot sink large currents, we added IC2 and IC3, which provide open collector outputs.

## 15. Hook-up Examples









### 16. Schematic diagram (Control section)



vellemen'

#### 17. Schematic diagram (Receiver section)



# 18. Control PCB





#### 19. Receiver PCB

PCB





Modifications and typographical errors reserved © Velleman Components nv. H8023IP - 2004 - ED1

