

High Temperature Parts

Transducers

Part Number	Operating Temperature
<u>AT-1127-ST-HT-R</u>	-40°C to +85°C
<u>AT-1620-TWT-HT-R</u>	-40°C to +85°C
<u>AT-2508-TT-HT-R</u>	-40°C to +85°C
<u>AT-3411-T-HT-LW110-R</u>	-30°C to +85°C
<u>AT-4625-TT-HT-R</u>	-40°C to +105°C
<u>SMT-0440-T-HT-R</u>	-40°C to +105°C
<u>SMT-0825-S-HT-R</u>	-40°C to +105°C
<u>SMT-0825-T-HT-R</u>	-40°C to +105°C
<u>SMT-0827-S-HT-R</u>	-40°C to +105°C
<u>SMT-0827-T-HT-R</u>	-40°C to +105°C

SMT-0830-T-HT-R

-40°C to +105°C

SMT-0927-S-HT-R

-40°C to +105°C

SMT-1027-S-HT-2-R

-40°C to +105°C

SMT-1027-S-HT-R

-40°C to +105°C

SMT-1320-T-HT-R

-40°C to +105°C

SMT-1324-TW-1V-HT-R

-40°C to +105°C

SMT-1341-T-HT-R

-40°C to +105°C

SMT-1427-S-5V-HT-R

-40°C to +105°C

AT-4625-TT-HT-R

